


Polycom® K IRK® 2010



User Guide

DEAR CUSTOMER

We would like to thank you for purchasing the telephone.

We hope you will enjoy it.

Please read the following thoroughly and observe the operating instructions and information provided.

NOTE: To subscribe the handset, please use the SN (IPEI) number, which you find on the handset label and the box label.

Copyright ©. All rights reserved. All forms of copying or reproduction of the product or its associated user guide are strictly prohibited.

Package Contents

The following items are included in the package:

- One DECT handset unit

NOTE: Additional handsets may be included according to product package.

- One charger unit

- Three rechargeable batteries (1.2V 600 mAh per battery)


- One power supply unit

- One user's guide

IN THIS GUIDE

HANDSET COMPONENTS	6
Handset Units	7
INSTALLING THE BATTERIES	8
LCD DISPLAYS AND SYMBOLS	9
HOW TO NAVIGATE THE MENU	10
EVERYDAY USE	11
Making a telephone call	11
Answering a telephone call	11
CALL HANDLING	11
Redial	11
View missed calls	11
View incoming calls	11
TELEPHONE BOOK	12
Entering text	12
Add new entry	12
View telephone book	13
Edit telephone book	13
FEATURES	13
Select language	13
Change ring pattern	14
Adjust volume	14
Key beeps	14
Keypad lock	15
Range indicator	15
Battery	16
GUIDE TO BASIC FUNCTIONS	17
TECHNICAL SPECIFICATIONS	18
TROUBLESHOOTING	18
INTERNATIONAL REGULATORY & PRODUCT INFORMATION	19
Important safety instruction	19
Intrinsic safety	20

HANDSET COMPONENTS



Handset







- | | |
|--------------------------------------|---|
| 1 Ear piece/Receiver | Transmits communications and audio signals |
| 2 LCD Screen | Displays the current status and function of the handset |
| 3 Headset jack
(optional) | Connects to external headset |
| 4 Function keys | Dials numbers and accesses handset functions |
| 5 Battery compartment | Contains three rechargeable batteries |
| 6 Mouth piece/ Microphone | Transmits communications and audio signals |
| 7 Handset charge contacts | Receives charging power from charger unit |

Charger Unit

- | | |
|----------------------------|---|
| 8 Power supply unit | Connects to AC power source |
| 9 Charger contacts | Supplies charging power to the rechargeable batteries |
| 10 Power indicator | Indicates power is applied to the charger unit |

Handset Unit

Before going through the keypad functions, review the multiple modes that are assigned to each button.

Button	In Standby mode	In Conversation Mode	In programming/Viewing Mode
 ON	Press this button to answer an incoming call or to make a call Press this button briefly to turn on the handset	This button switches between two lines	When reviewing phone book, redial list, or Caller ID records, press this button to start dialing
 OFF	Press and hold this button to turn off the handset	Press this to end a call	Press this button to return to standby mode
0 – 9	Press these keys to enter digits 0-9	Press these keys to send DTMF signal 0-9	Press these keys to enter digits 0-9
	No function	Press this button to mute the call	Press this button to go back to previous menu or to cancel an action
	Press this button to view phone book entries	Press this button to decrease receiver volume during conversation	Press this button to scroll through menu selection
OK 	Press this button to enter MENU mode		Press this button to confirm an action or a selection
	Press this button to enter the redial list	Press this button to activate or deactivate speakerphone mode	

INSTALLING THE BATTERIES


Follow these steps to install the batteries:

1. On the charger unit, plug in the power supply unit to the mains supply.
2. On the handset, gently slide the battery cover to open the compartment. Insert the rechargeable batteries that are provided with the package. Make sure the batteries follow the polarity indication marked inside the battery compartment. The LCD screen will turn on as soon as the batteries are inserted. Put the back cover back in place.
3. Place the handset in the charger unit as shown in the illustration. Make sure that the charge indicator on the base unit lights up and that the bars in the charge icon on the LCD screen scroll from bottom to top showing that charging is in progress.








Important! To obtain the best battery performance, charge the handset for at least 12 hours after installing the batteries.

Replacing the batteries

Depending on your usage, it is recommended to change the rechargeable batteries every year to achieve best performance.




LCD DISPLAYS AND SYMBOLS

Symbol	Description
	The antenna symbol indicates a good connection to the base Note: If the handset is out of range, the display will display NO NETWORK.
	Indicates when keypad lock is activated
	Indicates when the phone line is in use
	Indicates that the handset speakerphone mode is activated
	Indicates that the handset microphone is muted
	Indicates a graphical representation of the current battery capacity Note: During charging the bars in this symbol scroll from bottom to top. After the batteries are fully charged, the scrolling stops.
	Indicates that the handset is in standby mode Note: During standby mode, the assigned number is displayed.

HOW TO NAVIGATE THE MENU


To access press **OK** during idle state and navigate by using ▲ and ▼. Press **OK** to select menu item. Pressing ◀ takes you back one level. To leave the menu or cancel long press ▶.




EVERYDAY USE

MAKING A TELEPHONE CALL

Post dialling

Press off hook  -key and wait for the dialling tone. Then, dial the desired telephone number with the numeric keys.

To end a call push the hook  -key.


Pre-dialling

When the telephone is on-hook, enter the telephone number and press off hook. The number will now be dialled.

Speakerphone

Enter the telephone number and press . When contact is made speak through the microphone. To end a speakerphone call press .

ANSWERING A TELEPHONE CALL

When the telephone rings, lift handset and begin conversation. The number of the caller will be displayed. Pressing  mutes the incoming calls.

CALL HANDLING

REDIAL

To redial a telephone number press  when the telephone is in idle state. Navigate using  and .



Press  to dial a number.


VIEW MISSED CALLS

To view a list of missed calls press  when the telephone is in idle state.

Press  to dial a number.

VIEW INCOMING CALLS

To view incoming calls, enter the **Menu** then **Call List**. Navigate using  and .

Press  to dial a number.

TELEPHONE BOOK

The telephone book lets you store up to 40 entries.

KEY CHARACTER SELECTION

1	.	,	1	-	?	!	:	'	()
2	A	B	C	2	À	Á	Â	Ã	Ä	Å
3	D	E	F	3	Ď	È	É	Ê	Ë	Ě
4	G	H	I	4	ǧ	ì	í	î	ï	ĭ
5	J	K	L	5	Ĳ	Ł	Ł	Ł	Λ	Π
6	M	N	O	6	Ñ	Ń	Ň	Ö	Ó	Ô
7	P	Q	R	5	7	Ř	Ř	Ś	Š	Ş
8	T	U	V	8	ƴ	Ù	Ú	Û	Ü	Û
9	W	X	Y	Z	9	Ŵ	Ý	·Y	ÿ	Ž
0	Space	0	+	&	@	/	\$	%		

1										
2	Æ	À	ç	Ć	Č	Б	Г			
3	ě	Δ	Z	Д	Ж	З				
4	ı	İ	θ	И	Й	Қ	Л			
5										
6	Ö	Ö	Ø	Θ	Υ					
7	β	Π	Σ	Φ	Ц	Ч				
8	Ф	Ш	Щ	Ъ	Ы					
9	Ž	Ž	Ψ	Ω		b	э	Ю	Я	
0										

ENTERING TEXT

The numeric keys can also be used for entering letters. This is useful for storing contacts in the telephone book.

In the text editor press **2** once for the letter A, press **6** twice for the letter N etc.

To delete a character press  and long press to exit menu.


While you select a character the cursor will be invisible. Upon release of a key wait one second for the cursor to move to the next slot and proceed entering characters.

ADD NEW ENTRY

You can add a new entry to the telephone book in three different ways:

1. On-hook

Enter the number when on-hook. Press  and then  and **OK**. Enter a name for the contact and press **OK** to save.


1	2	3	4	5	6	7	8			OK	John Smith	OK
---	---	---	---	---	---	---	---	---	---	-----------	------------	-----------

Remark: to insert space in between two names press **0** .




2. Via the menu

Press **OK** to enter the menu and find the item **PHONE BOOK**. Choose **ADD ENTRY** and enter the telephone number. See point (1) for further instructions.

3. From the Call lists

You can also store a number shown in the calls lists (Received, Dialed and Missed calls). Press  when the telephone number is shown. See point (1) for further instructions.

VIEW TELEPHONE BOOK

The telephone book is accessed by pressing . To navigate the menu press  and . Entries can be accessed quickly by entering the first letter of the contact, i.e. press 6 once to view contacts beginning with M, press 3 twice to view contacts beginning with E etc.


To call a number from the telephone book press .

EDIT TELEPHONE BOOK

The edit option is only accessible via the menu. You can also choose to delete an entry.

FEATURES

SELECT LANGUAGE

To change menu language press **OK** to enter the main menu. Find the **LANGUAGE** menu and press **OK** to enter it. Select desirable language and press **OK** to save. Long press  to cancel and exit menu.

CHANGE RING PATTERN

Enter the menu and choose the item **RING MELODY**. Navigate melodies with ▲ and ▼. Each melody will be played as they are highlighted. To choose a melody press **OK**.

ADJUST VOLUME

Up/down

To adjust the volume enter the menu and choose **RING VOLUME**. Change volume with ▲ and ▼. Press **OK** to save.

Mute

To mute the microphone during call press Repeat to turn the microphone back on.

KEY BEEPS

Turn on/off

Press **OK** to enter menu. Press ▼ to find the item **KEY BEEPS** and press **OK**. Now choose **DISABLE** to turn key beep off or **ENABLE** to turn back on.

KEYPAD LOCK

To lock the keypad press **OK** followed by *****. Repeat to unlock. The  icon and **KEYS LOCKED!** displays on the screen.

RANGE INDICATOR

4 bars indicates the signal level.



Good coverage



OK coverage



Limited coverage



















Poor coverage

BATTERY

See battery level  in display.

- Talk time 12 hours.
- Standby time 150 hours.
- The battery icon will be flashing when the battery is low. This will be accompanied by a beep.

GUIDE TO BASIC FUNCTIONS

HOW TO	WHAT TO DO
Enter the menu	When telephone is in idle state (on-hook) press OK
Make a telephone call	Press off hook 
Answer a telephone call	When telephone rings press off hook 
Redial	Press  to view redial list To store press OK or off hook 
Dial received calls	Enter the Menu then Call list then Received and press OK .
Adjust volume	During call press  or  The volume level (1-6) will be displayed.
Mute microphone	During call press 
Change ring melody	Press OK to enter menu. Press  to find item RING MELODY . Browse the available melodies with  or  . Press OK to save melody
Disable key beeps	Press OK to enter menu. Press  to find item KEY BEEPS . Choose between enable or disable with  and  . Press OK to save
Lock the keypad	Press OK , then  . Repeat to unlock
Add entry to telephone book	Enter number when on-hook. Press  and then  . Enter name for contact

TECHNICAL SPECIFICATIONS

DECT/GAP compatible

Telephone book: 40 entries

Hands free operation

Setting of handset and
loudspeaker volume

10 Polyphonic melodies

2 line illuminated display,
12 digits/ 12 characters

Battery stand by time approx. 150 hours

Battery talk time approx. 12 hours

Caller ID

Redial: 10 entries

Call log: 10 entries

Missed calls: 10 entries

DTMF transmission

Operational temperature: 0-40°C

TROUBLESHOOTING

MY TELEPHONE DOES NOT WORK

Make sure that you have inserted batteries into the battery compartment, and that they are inserted with correct polarity.

Push the hook switch once and wait for dialling tone again.

If the person at the other end of the conversation does not hear your voice, make sure that you have not pressed Mute. To test, press the Mute button once more and your telephone should resume to normal operation.

You may be out of reach from a base. Please contact your service operator.

CALLER'S NUMBER DOES NOT SHOW ON MY TELEPHONE

Callers may suppress their caller's number when making their telephone call.

Caller's number does not necessarily display when a call is received.

If a call is made from abroad, caller's number cannot always be transmitted.

INTERNATIONAL REGULATORY & PRODUCT INFORMATION



This KIRK 2010 Handset has been marked with the CE mark. This mark indicates compliance with EEC Directives 89/336/EEC, 73/23/EEC 1999/5/EC. A full copy of the Declaration of conformity can be obtained from Polycom Ltd, 270 Bath Road, Slough, Berkshire, SL1 4DX, UK.



The WEEE Marking on this equipment indicates that the product must not be disposed of with unsorted waste, but must be collected separately.

IMPORTANT SAFETY INSTRUCTIONS

Before using your telephone equipment, you should always follow basic safety instruction to reduce the risk of fire, electrical shock and injury to persons, and damage to property.

1. Read and understand all instructions.
2. Follow all warnings and instructions including those marked on the product.
3. Unplug this product before cleaning. Do not use liquid cleaners or aerosol cleaners. Use damp cloth for cleaning.
4. Do not install the telephone equipment in the bathroom or near a wash bowl, kitchen sink, or laundry tub, in a wet basement, or near a swimming pool.
5. Slots or openings in the equipment are provided for ventilation to protect it from over-heating. These openings must not be blocked or covered.
6. The product should be operated only from the type of power source indicated on the instructions. If you are not sure of the type of power supply, consult your dealer or local power company.
7. Do not overload wall outlets and extension cords as this can result in fire or electrical shock.
8. Never push objects of any kind into this product through cabinet slots as they may touch dangerous voltage points or short out parts that could result in fire, electrical shock, or injury. Never spill liquid of any kind into this product.
9. To reduce the risk of electrical shock or burns, do not disassemble this product. Opening or removing covers may expose you to dangerous voltages, dangerous electrical current, or other risks. Incorrect reassemble can cause electrical shock when the appliance is subsequently used. If the product need repair, consult your dealer.
10. Refer servicing to qualified service personnel.

11. Avoid using telephone during an electrical storm. There may be a risk of electrical shock from lightning.
12. Do not use the telephone to report a gas leak in the vicinity of the leak.
13. Do not place the base or charger near microwave ovens, radio equipment, or non-ground connected televisions. These appliances may cause electrical interference to the base or handset.
14. The charger must be placed on a hard, flat surface and connected to a functional 120 volt AC power source depending on the country of use.
15. This telephone will not operate in the event of a blackout. Please keep a backup phone for emergencies.
16. Installation must be performed in accordance with all relevant national wiring rules.
17. Plug acts as Disconnect Device - The socket outlet to which this apparatus is connected must be installed near the equipment and must always be readily accessible.
18. This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

INTRINSIC SAFETY

Do not use the handset in conditions where there is a danger of electrically ignited explosions.

Exposure to sunlight, heat and moisture

Do not expose the wireless phone to direct sunlight for long periods. Keep the wireless phone away from excessive heat and moisture.

Spare parts and accessories

Use only approved spare parts and accessories. The operation of non- approved parts cannot be guaranteed and may even cause damage.

Power failure

In the event of a power failure or flat battery, you cannot use the handset to make or receive calls.

Battery Precautions

1. Periodically clean the charge contacts on both the charger and handset.
2. Exercise care in handling batteries in order not to short the batteries with conducting materials such as rings, bracelets, and keys. The batteries or conducting material may overheat and cause burns or fire.
3. Do not open or mutilate the batteries. Released electrolyte is corrosive and may cause damage to the eyes or skin. The electrolyte may be toxic if swallowed.
4. During charging batteries heat up. This is normal and not dangerous.
5. Lithium cell installation Caution - Danger of Explosion if Battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.

NOTICES

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. The customer should be aware that compliance with the above conditions may not prevent degradation of service in some situations. Repairs to certified equipment should be coordinated by a representative designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment. Users should ensure for their own protection that the electrical ground connections of the power utility, telephone lines and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.

EMC CAUTIONS: Users should not attempt to make such connections themselves, but should contact the appropriate electric inspection authority, or electrician, as appropriate. If your telephone equipment causes harm to the telephone network, the telephone company may ask you to disconnect the system from the line until the problem has been corrected or they may discontinue your service temporarily. If possible, they will notify you in advance. But if advance notice is not practical, you should be notified as soon as possible. You will be informed of your right to file a complaint with the FCC. Your telephone company may make changes in its facilities, equipment, operations, or procedures that could affect the proper functioning of your telephone system, If they do and it is possible, you will be notified in advance to give you an opportunity to maintain uninterrupted telephone service. If you experience trouble with this telephone system, disconnect it from the network until the problem has been corrected or until you are sure that the equipment is not malfunctioning.

Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to local regulations. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Note: This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

SAR: Device has been tested for SAR compliance for head and body worn configurations. The highest reported SAR values are: head 0.056 W/kg, and body worn 0.017 W/kg

IC Note: Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

The Term iICI: before the certification/registration number only signifies that the Industry Canada technical specifications were met.

Privacy of communications may not be ensured when using this telephone.

Power Outage: In the event of a power outage, your wireless telephone will not operate. The wireless telephone requires electricity for operation. You should have a telephone which does not require electricity available for use during power outages.

Information to user: The users manual or instruction manual for an intentional or unintentional radiator shall caution the user that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE EMC: Cet appareil a été soumis à un essai et jugé conforme aux normes régissant les limites établies pour un dispositif numérique de classe B, conformément aux règlements locaux. Ces limites visent à assurer une protection raisonnable contre des interférences pouvant nuire à l'appareil utilisé dans un secteur résidentiel. Cet équipement génère et utilise des radiofréquences, et peut en émettre. S'il n'est pas installé et utilisé selon les directives fournies, il risque de perturber les radiocommunications. L'exploitation de cet appareil dans un secteur particulier est toutefois susceptible de produire des interférences nuisibles. Si cet équipement provoque des interférences lors de la réception des radiofréquences ou des fréquences de télévision, ce qui peut être vérifié en mettant l'appareil hors tension, puis en le remettant sous tension, l'utilisateur doit prendre l'une des mesures suivantes pour corriger la situation:

- réorienter ou relocaliser l'antenne de réception;
- augmenter la distance entre l'appareil et l'antenne de réception;
- brancher l'appareil à une prise d'un circuit différent de celui auquel l'antenne est branchée;
- consulter le détaillant ou un technicien en radiotélévision d'expérience pour obtenir de l'aide.